



Olon Wall Moulding Installation Guide

1. Preparation:

- Measure the wall space to determine the quantity of Olon Wall Mouldings required.
- Allow mouldings to sit in the room for 48–72 hours to acclimate to humidity.
- Ensure walls are clean, dry, and structurally sound.
- Use a stud finder to locate and mark wall studs for nailing.
- If gluing, use a construction adhesive (e.g., Liquid Nails, Loctite, PL Premium).
- Cut mouldings to size, staggering cut ends from row to row.
- For uneven walls or insulation improvement, install furring strips before moulding.
- For melamine or non-porous surfaces, use an appropriate adhesive (e.g., Titebond, Roo Glue).

Note: Furring strips are easily removable and protect drywall for temporary applications. For permanent installation, apply adhesive.

2. Horizontal Installation:

- Since mouldings cross multiple studs, furring strips are unnecessary when both gluing and nailing.
 - Start with the first (bottom) row, ensuring it is level and aligned with the floor.
 - Position the moulding so the exposed lower tongue faces upward to receive the groove of the next board.
 - Apply adhesive to the back of each moulding.
 - Secure with brad nails through the tongue at the top of the board into studs.
 - Stagger cut ends between rows for strength and aesthetics.
 - Continue installing upward, overlapping each new board onto the one below.
 - Cut boards as needed to fit around outlets, windows, and obstacles.
-

3. Vertical Installation:

- If using furring strips, install them horizontally across studs to provide extra nailing points (optional unless skipping adhesive).
 - Begin with the first vertical moulding, ensuring it is plumb and aligned with the starting wall or corner.
 - Position the moulding so the exposed lower tongue faces outward to receive the next piece.
 - Apply adhesive to the back of each moulding.
 - Secure with brad nails through the exposed tongue at the side of the board into studs.
 - Stagger cut ends between rows for strength and aesthetics.
 - Continue installing across the wall, overlapping each new board onto the previous one.
 - Cut boards as needed to fit around outlets, windows, and obstacles.
-

4. Finishing:

- If necessary, add matching finishing mouldings, baseboards, or trim to cover gaps or unfinished edges around the moulding installation as needed.
-